

Diagnoza własna samochodu
007 - Kodowanie (usługa 1A)
Wybierz wartość kodu

09 - Centralny układ elektroniczny
3C0937049D 3C0937049D
Bordnetz-SG H37 H37 1002
Kodowanie długi
Numer serwisu 380

10 (\$A)	\$00	00000000	▲
11 (\$B)	\$00	00000000	
12 (\$C)	\$14	00010100	
13 (\$D)	\$00	00000000	
14 (\$E)	\$00	00000000	
15 (\$F)	\$00	00000000	
16 (\$10)	\$00	00000000	
17 (\$11)	\$09	00001001	
18 (\$12)	\$7B	01111011	
19 (\$13)	\$07	00000111	
20 (\$14)	\$5C	01011100	▼

**PROCEDURE HOW TO SWITCH OFF
WARNING LIGHTS
(WHICH FLASHES DURING SUDDEN BRAKE)**

VAS 5051

1. 09 - BORDNETZ – SG
2. 007 – CODING

CHOOSE BORDNETZ

IN POSITION 17 PLEASE CHANGE 09 ON 08 AND CONFIRM

